



ASSEMBLY INSTRUCTION

A	B	C	D	E	F	G	H
							
x1	x1	x1	x1	x1	M6x45 x2	M6x16 x4	M6x22 x6
I	J	Spare Parts		Spare Parts	Spare Parts		
							
x2	#5 x1	M6x45 x1	M6x16 x1	x1	x1		


STEP 1



STEP 2



STEP 3



STEP 4

